

impact™



Fresnel Spot S-Mount Attachment
10°–40°

INSTRUCTIONS

Introduction

Thank you for choosing Impact.

The Impact LM-FSA1040 is an innovative light-shaping tool that is compatible with studio strobes or LEDs with Bowens S-mounts or S-mount adapters.

The glass fresnel lens provides dramatic lighting options by focusing your light from a concentrated 10% spot to a wide 40% flood. Whether in the flood or spot position, the Fresnel Spot delivers the ability to focus on a specific area with even light and a well-defined beam. Four colored gels that quickly snap into place are included to offer a variety of special effects.

Precautions

- Use only LED lights that draw up to 150 W or monolight flashes up to 1,000 W/s.
- Flashes that include tungsten modeling lights of 150 W or less should be used for a maximum of 30 seconds only.
- Allow tungsten lights to cool before reuse.
- Please read and follow these instructions, and keep this manual in a safe place.
- Keep this unit away from water and any flammable gases or liquids.
- Make sure that this product is intact and that there are no missing parts.
- Do not stare at the lights when they are powered on.
- All photos are for illustrative purposes only.

Box Contents

1. Fresnel spot attachment
2. Colored gels (×4)
3. Carry pouch
4. User manual



Instructions

Attaching the LM-FSA1040

1. Align the tabs of the fresnel housing mounting ring with the slots of the Bowens S-mount and insert the fresnel into the mount.
2. Rotate the housing clockwise until it locks into place.

Note: It's recommended to do this with the housing in the shortest (closed) position.

Focusing Your Light

For a narrow beam, rotate the lens clockwise until the desired beam angle is achieved.

Use the housing to rotate the fresnel spot whenever a beam adjustment is needed.



Instructions

Using Gels

To attach a gel to the fresnel, follow these steps:

1. Align the slots in the gel's mounting frame with the tabs on the fresnel. Make sure that the arrow on the gel's frame is pointing toward the locking button.
2. Gently press the gel down and turn it counterclockwise until the locking button pops up and locks the gel into place.

To remove the gel from the fresnel, press down on the locking button and turn the gel clockwise until it can be removed from the mounting frame.



Specifications

Specifications	
Diameter	5" (12.7 cm)
Length (flood position)	4.5" (11.4 cm)
Length (spot position)	6" (15.2 cm)
Weight	1.3 lb. (0.6 kg)

One-Year Limited Warranty

This IMPACT product is warranted to the original purchaser to be free from defects in materials and workmanship under normal consumer use for a period of one (1) year from the original purchase date or thirty (30) days after replacement, whichever occurs later. The warranty provider's responsibility with respect to this limited warranty shall be limited solely to repair or replacement, at the provider's discretion, of any product that fails during normal use of this product in its intended manner and in its intended environment. Inoperability of the product or part(s) shall be determined by the warranty provider. If the product has been discontinued, the warranty provider reserves the right to replace it with a model of equivalent quality and function.

This warranty does not cover damage or defect caused by misuse, neglect, accident, alteration, abuse, improper installation or maintenance. EXCEPT AS PROVIDED HEREIN, THE WARRANTY PROVIDER MAKES NEITHER ANY EXPRESS WARRANTIES NOR ANY IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. This warranty provides you with specific legal rights, and you may also have additional rights that vary from state to state.

To obtain warranty coverage, contact the Impact Customer Service Department to obtain a return merchandise authorization ("RMA") number, and return the defective product to Impact along with the RMA number and proof of purchase. Shipment of the defective product is at the purchaser's own risk and expense.

For more information or to arrange service, visit www.impactstudiolighting.com or call Customer Service at 212-594-2353.



Product warranty provided by the Gradus Group.
www.gradusgroup.com

IMPACT is a registered trademark of the Gradus Group.

© 2015 Gradus Group LLC. All Rights Reserved.